Designed and engineered in North America. Made in China.

Paradigm Electronics Inc. In the U.S.: MPO Box 2410, Niagara Falls, NY 14302 In Canada/International: 205 Annagem Blvd., Mississauga, ON L5T 2V1

without notice as design improvements are incorporated.

Paradigm

Paradigm Electronics reserves the right to change specifications and/or features

- Iong periods of time. 13) Unplug this apparatus during lightning storms or when unused for
- rain or moisture, does not operate normally, or has been dropped. bave fallen into the apparatus, the apparatus has been exposed to stoply cord or plug is damaged, liquid has been splited or objects when the apparatus has been damaged in any way, such as power-14) Refer all servicing to qualified service personnel. Servicing is required
- VASES, ARE PLACED ON THE APPARATUS. AND ENSURE THAT NO OBJECTS FILLED WITH LIQUIDS, SUCH AS ONIHSAJAS AO ONIAGIAO OT TNAMAIUDA SIHT ASOAXA TON OO (CI
- AC RECEPTACLE. MAINS, DISCONNECT THE POWER SUPPLY CORD PLUG FROM THE 16) TO COMPLETELY DISCONNECT THIS APPARATUS FROM THE AC
- .318AA390 YJIDA3A VIAMAR PLUG OF THE POWER SUPPLY CORD SHALL REMAIN

Paradigm® PT-2 is warranted to be and remain free of manufacturing and/or material defects for a period of three (3) years from the date of the original retail purchase. Within this specified period, repair, replacement or adjustment of parts for manufacturing and/or material defects will be free of charge.

• Warranty begins on date of original retail purchase from an Authorized

· Warranty applies to product in normal home use only. If the product is subjected to any of the conditions outlined in the next section, warranty is void;

· Warranty does not apply if the product is used in professional or commercial

The product has been used in conjunction with unsuitable or faulty equipment.

• The product has been subjected to damaging signals, derangement in

The product (including cabinet) has been tampered with or damaged by an

Thermal or mechanical abuse/misuse is not covered under warranty.

• The product has been abused (intentionally or accidentally);

transport, mechanical damage or any abnormal conditions;

• The serial number has been removed or defaced.

Paradigm[®] Dealer only. It is not transferable;

Limitations:

applications.

Warranty is Void if:

unauthorized service facility:

WARRANTY

njury trom tip-over.

.suterequeration

moving the cart/ apparatus combination, to avoid

apparatus. When a cart is used, use caution when

specified by the manufacturer or sold with the

(1) Only use attachments/accessories specified by the manufacturer.

at plugs, convenience receptacles, and the point where they exit from ID Protect the power cord from being walked on or pinched particularly

brovided plug does not it into your outlet, consult an electrician for

wide blade or the third prong are provided for your safety. If the

grounding type plug has two blades and a third grounding prong. The

plug. A polarized plug has two blades with one wider than the other. A

9) Do not detect the safety purpose of the polarized or grounding-type

7) Do not block any ventilation openings. Install in accordance with the

stoves, or other apparatus (including amplifiers) that produce heat. 8) Do not install near any heat sources such as radiators, heat registers,

12) Use only with the cart, stand, tripod, bracket, or table

replacement of the obsolete outlet.

manutacturer's instructions.

Clean only with dry a cloth.

Follow all instructions.

Keep these instructions.

Read these instructions.

.spninnew lle beeH

٢C

ſt

ເຄ

5)

Do not use this apparatus near water.

SNOITJUATSNI YTJAS TNATAOGMI

What You Are Responsible For:

so this exclusion may not apply to you.

of purchase.

website at www.paradigm.com for more information.

- your Authorized Paradigm[®] Dealer).

- Provide or pay for transportation charges for product to service facility;
- · Provide proof of purchase (your sales receipt given at time of purchase from

Should servicing be required, contact your nearest Authorized Paradigm®

Reference Dealer, Paradigm Electronics Inc., or Import Distributor (outside the

U.S. and Canada) to arrange, bring in or ship prepaid any defective unit. Visit our

Paradigm Electronics Inc. reserves the right to improve the design of any product without assuming any obligation to modify any product previously manufactured.

This warranty is in lieu of all other warranties expressed or implied, of

merchantability, fitness for any particular purpose and may not be extended or


enlarged by anyone. In no event shall Paradigm Electronics Inc., their agents, or

representatives be responsible for any incidental or consequential damages.

Some jurisdictions do not allow limitation of incidental or consequential damages,

Retain this manual and your sales receipt for proof of warranty term and proof

- Provide normal/reasonable operating care and maintenance;



maintenance (Servicing) instructions in the the presence of important operating and triangle is intended to alert the user to The exclamation point within an equilateral

TYPE. REFER REPLACEMENT TO QUALIFIED SERVICE PERSONNEL. REPLACE THE FUSE ONLY WITH THE SAME AMPERAGE AND VOLTAGE **CAUTION:** FOR CONTINUED PROTECTION AGAINST RISK OF FIRE,

Itterature accompanying the product.

SOURCE, OR IN SPACES THAT CAN RESTRICT VENTILATION. VENTILATION TO ALLOW FOR COOLING. DO NOT PLACE NEAR A HEAT WARNING: UNIT MAY BECOME HOT. ALWAYS PROVIDE ADEQUATE





SERVICING TO QUALIFIED SERVICE PERSONNEL. NO USER-SERVICEABLE PARTS INSIDE. REFER SHOCK, DO NOT REMOVE COVER (OR BACK). WARNING: TO REDUCE THE RISK OF ELECTRIC

DO NOT OPEN

BISK OF ELECTRIC SHOCK

. SUTARA99A SIHT FILLED WITH LIQUIDS, SUCH AS VASES, SHOULD NOT BE PLACED ON NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE, AND OBJECTS WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO

PLUG TO WIDE SLOT, FULLY INSERT. CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF

ABOUT YOUR PT-2 TRANSMITTER

In a typical listening room the PT-2 transmitter has a **maximum range of 50' (15 m)**. Obstructions such as walls, large pieces of furniture, room dividers, etc., may reduce this range. Do not place subwoofer(s) and transmitter farther apart than the recommended range. The PT-2 is a 2.4 GHz digital design that automatically adjusts for best wireless connection while constantly monitoring the integrity of the data stream. An RCA audio cable is required *(not included)* to connect it to your A/V receiver or preamplifier *(see dealer)*.

One PT-2 transmitter can be used with up to four wireless Paradigm subwoofers. See dealer for full details on connecting multiple subwoofers.

Zone 2 Operation

Your PT-2 transmitter will work with a subwoofer(s) in a second zone (i.e. another area of your home).


TIP! To minimize the chance of signal dropouts or signal interference, keep the PT-2 transmitter out of range of a microwave oven, mobile telephone or a Bluetooth device operating on the same frequency.




IMPORTANT! Paradigm recommends using speaker-level OR line-level connections. DO NOT USE BOTH CONNECTIONS AT THE SAME TIME.

Your PT-2 transmitter is designed to work with Paradigm brand subwoofers only.


PANEL LAYOUTS






LINE-LEVEL CONNECTION (NO SUB-OUT/LFE): VOLUME CONTROLLED BY RECEIVER

Receiver without bass management.



WIRELESS SYNC INSTRUCTIONS



- 1. Plug in PT-2 wireless transmitter.
- 2. Press and hold sync button (A) on front panel of PT-2 for 3 seconds. The LED (B) will blink quickly.
- 3. Within 60 secs of pressing the sync button all subwoofers must be plugged in. Once all subwoofers are synched, the LED will remain 'on'.

TIP! Once all subwoofers have been synched, if necessary they can be unplugged and moved without resynching again.

LATENCY SWITCH INSTRUCTIONS

The latency switch \bigcirc adjusts the delay between the PT-2's audio signal input and the subwoofer receiver's RF output, optimizing integrity of the wireless transmission. Start with the switch in the 15ms position. If you experience sound quality issues (i.e drop-outs, pops, ticks), you can improve the connection by moving the switch to 20ms or 25ms to increase latency.

LED STATUS

Off: No power.

Fast blinking: Set-up mode.


Dim: Unit in standby mode, no transmission.

Slow blinking, 'off' to bright: Waking from standby mode and synching.

Slow blinking, dim to bright: At least one subwoofer is synched. Permanently On: All subwoofers synched and receiving signal.


SPEAKER-LEVEL CONNECTION: VOLUME CONTROLLED EXTERNALLY (ZONE 2)

Receiver without line-level connection.



LINE-LEVEL CONNECTION (WITH SUB-OUT/LFE): VOLUME CONTROLLED BY RECEIVER

Receiver with bass management.






Wireless Subwoofer

SPEAKER-LEVEL CONNECTION, VOLUME CONTROLLED BY RECEIVER

Volume Control occurs at receiver.



Zone 2 volume level of full-range speakers and subwoofer may be controlled by the Paradigm VC-150 Volume Control *(sold separately)*. Requires running speaker wire from the Paradigm VC-150 Volume Control back to the Paradigm PT-2 transmitter.

This device contains FCC ID: YZY-HT205 and IC ID: 9261A-HT205. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.



RECYCLING AND REUSE GUIDELINES FOR EUROPE

In accordance with the European Union WEEE (Waste Electrical and Electronic Equipment) directive effective August 13, 2005, we would like to notify you that this product may contain regulated materials which, upon disposal, according to the WEEE directive, require special reuse and recycling processing. For this reason Paradigm Electronics Inc. (manufacturers of Paradigm speakers and Anthem electronics) has arranged with our distributors in European Union member nations to collect and recycle this product at no cost to you. To find your local distributor please contact the dealer from whom you purchased this product or go to our website at **www.paradigm.com**.

Please note that the product only falls under the WEEE directive. When disposing of packaging and other shipping material we encourage you to recycle through the normal channels.